

Intake Manifold Options

Having trouble determining which FAST™ intake manifold is the right one for your application? The diagram below can help. Find your LS application in one of the application boxes below and follow the lines to determine the proper intake manifold part number, along with fuel rail options and other required and optional accessory pieces. Please refer to these diagrams as some parts are REQUIRED with the installation of a FAST™ intake manifold.

LSX_R™ 102mm Intake Manifold (Rectangle, Raised Rectangle & Cathedral Port)

LSX_R™ 102mm Intake Manifold (Rectangle, Raised Rectangle & Cathedral Port)



1 Requires injector lower o-ring swap (included with manifold)
 2 Except Corvette, call FAST™ for throttle body recommendations
 3 Except 1997-1998 Corvettes

LSX_{RT}™ 102mm Intake Manifold (Cathedral Port)

LSX_{RT}™ 102mm Intake Manifold (Cathedral Port)



1 Permanent modification to OEM fuel rail required
 2 For use with OEM GM Truck/SUV injectors and FAST™ LS2 Injectors
 3 Requires injector lower o-ring swap when using OEM injectors (included with manifold)
 4 Excludes 2006 Trailblazer SS, some cowl modifications required
 5 Includes 2006 Trailblazer SS, some cowl modifications required
 6 Requires GM Purge Solenoid #12581282 (not sold by FAST™)