



**Pinout and Wire list for FAST Engine Harness (part #30-C001)**

**CONNECTOR PART NUMBER LIST**

If you need to purchase additional connectors to complete your wiring, the following part numbers should assist you in locating the parts you need. All part numbers are Delphi/Packard part numbers.

Connector	Part number	Terminal	Insulating seal
<b>Weatherpack connectors</b>			
1 pin male	1201 5791	1208 9188L	1201 5323
1 pin female	1201 0996	1208 9040L	1201 5323
2 pin male	1201 5792	1208 9188L	1201 5323
2 pin female	1201 0973	1208 9040L	1201 5323
2 pin male (gray)	1210 3784	1208 9188L	1201 5323
2 pin female (gray)	1203 4074	1208 9040L	1201 5323
3 pin male	1201 5793	1208 9188L	1201 5323
3 pin female	1201 0717	1208 9040L	1201 5323
3 pin male (green)	1202 0403	1208 9188L	1201 5323
4 pin male	1202 0832	1208 9188L	1201 5323
4 pin female	??????????	1208 9040L	1201 5323
4 pin male (square)	1201 5798	1208 9188L	1201 5323
4 pin female (square)	1201 5024	1208 9040L	1201 5323
<b>Temperature sensor connectors</b>			
Air temperature	1216 2198	1212 4075	Included
Water temperature	1216 2193	1212 4075	Included
<b>Metripack connectors</b>			
3 pin male	1211 0293	1204 8074	1204 8086
3 pin female	1212 9615	1204 5773	1204 8086
3 pin male (round)	1206 5287	1210 3881	Included
4 pin male	1216 2187	1212 4075	1204 8086
7 pin male	1204 7938	1204 8074	1204 8086
7 pin female	1204 7933	1204 5773	1204 8086
10 pin male	1206 5425	1204 8074	1204 8086
10 pin female	1204 5808	1204 5773	1204 8086
<b>Other connectors</b>			
30 pin male (rows A-K)	1203 4398	1210 3881	Included
30 pin male (rows L-Y)	1203 4400	1210 3881	Included
Inline fuse holder	1203 3769	*See note	Included
Relay socket	1206 5971	*See note	Included

*\*Note: Use terminal 1202 0156 for 12 gauge wire. Use terminal 1203 3997 for 16 gauge wire.*